

SPILL KIT

GENERAL INFORMATION

Spill kits must be equipped with the type and quantity of spill equipment adequate to respond to a spill or release of the hazardous material that is stored or used in an operational area. Spill materials for cleanup and to restock spill kits may be procured from a local vendor or GSA.

The Environmental Compliance Inspection Checklist contains a general inventory for spill kits:

- Granular absorbent in new dry sweep container with lid (50 pounds)
- Absorbent pillows (5 ea) or pads (bundle of 100)
- Straight edge, non-sparking shovel (1 ea)
- Broom (1 ea)
- Used dry sweep container with lid (1 ea)
- Rubber gloves (2 pair)
- Rubber boots (2 pair)
- Absorbent booms, 8 or 10 feet long (2 ea)



HANDLING AND DISPOSAL PROCEDURES

Step 1: Report all spills to the DPW Emergency Spill Response Line at 656-1111. Spills over one (1) gallon must be reported in writing using the USAG-HI Spill Notification Form. The form can be downloaded from the ECO website at:

<https://dpwhawaii.army.mil/eco>.

Step 2: Spill kits must be marked/labeled “SPILL KIT”.

Step 3: Used spill response materials become hazardous or non-regulated waste depending on the material that is cleaned up. See spill response fact sheet for clean up and management procedures.

For more info contact: DPW Environmental Compliance Inspections Program.