



KTA WASH FACILITY

5 Bay Wash Area

**CONTACT INFORMATION M-F 0800-1530
NO AFTER HOURS SUPPORT**

**For Operational or Equipment Failure Assistance:
Contact DP&R at 655-5947 or 260-5551**



OPERATING PROCEDURE

1. Fill out required information on sign in sheet prior to use and upon completion. **Mandatory** for all vehicles that enter the range to wash vehicle prior to leaving KTA.
2. Open **West Gate** (Entrance Gate) then open **East Gate** (Exit Gate).
3. Locate the **Spray gun** and attached the spray Nozzle before attaching to the Hose.
4. Open Swamp Gate #1 until full then open Swamp Gate #2.
5. Open swamp valve. (**Especially when using the power hose**).
6. OPEN Door on Building 51
7. Turn on all 12-High Pressure Water Pumps and then open Roll-Up Gate.
8. Turn High Pressure Water Pumps to HAND When necessary (**Insure swamp valve is open**)
9. Inspect water tank to insure that water indicator is not less than 15,000 gallons (Marker 10).

Closing

1. **Turn OFF** 12-High Pressure Water Pumps
2. Turn High Pressure Water Pumps to OFF and Pull Lever to OFF Position.
3. **Turn Off** swamp valve counter clockwise
4. **Closed** all doors and Gates
5. Turn in utilization report to RC and water level and any discrepancy or deficiency

OPERATING FLOW CHART



Open Main Entrance

Instructions:

- The Gates will open in two direction
- Assist on the gate going west
- Push gate going east and place chain on the Hook to hold the gate in place.



Open west/entrance gate

Push Gate upward




Place Chain on the HOOK

Open Exit Gate

Instructions:


- Open Lock
- Gently Push both gate OPEN



Place the SPRAY Gun

Instructions:

- Insert SPRAY Tip On Gun
- Insert the Gun on the Hose



Insert the Gun to the Hose





Insert SPRAY Tip On Gun

Open Swamp Gate

Instructions:

- Lift to Open
- Push down to close
- Only open the swamp gate that need to be used



Open Swamp Valve

Instructions:


- **SKIP** step if Power Hose is not use.
- **MUST Open Swamp Valve First,** Prior turning ON the power.



Open Building 51

Instructions:

- Proceed to stairwell and open the door on the right which is an entrance to the power room



Latrine


Entrance to the
Power Room



Turn on Power Gun

Instructions:

- All 12 machine is located on the right Hand side as you come IN.
- Push the ON/OFF button to turn it ON (Green Light). Don't have to be in sequence.
- You may only turn on what you need.





Push
Button
to Power



Turn on Power HOSE

Instructions:


- **SKIP** step if Power Hose is not use.
- As you face the two panel. Use the panel on the right.
- Push Lever Upward to turn on
- Place the switch on the Hand Only




Do not touch These buttons

Do not Touch this Button

1. Push lever Upward to ON position



Do not Touch any of this Valve



2. Turn BOTH knob to HAND position

Wash AREA



Wash the vehicle inside the red line

1



2

3

4

5

How to operate the two Rails



**Pull pin to
Turn Rails**



OIC / NCOIC WASH FACILITY BRIEF

1. Ground Guide will be used at all times
2. Wash military vehicles only. (No POV's are allowed on the facilities)
3. Used chalk block when park.
4. Absolutely **"NO"** washing of the **ENGINE** compartments.
5. **NO** washing outside the red broken line.
6. Do NOT drop drain plugs (Stryker, Fox, MRAPs vehicles)
7. NO vehicle maintenance to be conducted on the facility (Emergency only)
8. This is a **RINSE FACILITY ONLY**; Absolutely NO soaps or cleaners are used to clean the vehicles
9. NO smoking and NO horseplay allowed.
10. All Trash will be taken out with the using unit.
11. **SAFETY**... Eye Pro must be used when operating and when with in 10 meters of the wash area.
12. Absolutely NO dumping of any hazardous Materials
13. Upon Completion:
 1. Bays are cleaned and rinse of Debris and Mud
 2. Ensure all equipment are properly restored to its original state
 3. Turn in status to RC of Number of Personnel, Number of vehicle and type on site.